



battery monitor
BMV-602

victron energy
BLUE POWER


Included




Battery monitor



Shunt



UTP cable




Pos. supply cable (x2)


WARNING

Please read this guide carefully to avoid wrong connections that cause battery monitor malfunction and/or fire hazards


Disconnect the negative pole of the battery before installation!




Wiring diagram




Connect the negative pole of the battery last !



Method A





OR

Method B

